

GOSONIC PRICE LIST

MODEL NO	DESCRIPTION	UNIT PRICE (CAD)
GSD-1112	MINI HI FI MUSIC SYSTEM	34,00
GSD-1116	MINI HI FI MUSIC SYSTEM	UNDER PRODUCTION
GSD-1111	MINI HI FI MUSIC SYSTEM	31,00
GSD-1109	MINI HI FI MUSIC SYSTEM	31,00
GSD-1326	MINI HI FI SYSTEM	42,00
GSD-1439	MINI HI FI SYSTEM	NO MORE AVAILABLE
GSD-1108	MICRO TOWER MUSIC SYSTEM	NO MORE AVAILABLE
GSD-1106	MICRO TOWER MUSIC SYSTEM	NO MORE AVAILABLE
GSD-1037	PORTABLE DVD PLAYER	NO MORE AVAILABLE
GSD-1036	PORTABLE DVD PLAYER	NO MORE AVAILABLE
GHT-1605	5.1 HOME THEATRE SYSTEM	42,00
GHT-1645	5.1 HOME THEATRE SYSTEM	42,00
GSD-1302	MINI HI-FI MUSIC SYSTEM	25,00
GPD-1393	PORTABLE DVD PLAYER	35,00
GDR-1369	DVD RECORDER	NO MORE AVAILABLE
GSD-1292	DVD PLAYER	22,00
GSD-1297	DVD PLAYER	22,00
GSD-1248	DVD PLAYER	22,00
GSD-1249	DVD PLAYER	22,00
GSD-1221	DVD PLAYER	22,00
GSD-1247	DVD PLAYER	21,00
GSD-1243	DVD PLAYER	21,00
GSD-1209	DVD PLAYER	18,00
GSD-1208	DVD PLAYER	18,00
GSD-1202	DVD PLAYER	18,00
GSD-1201	DVD PLAYER	17,00
GSN-991	MINI HI FI MUSIC SYSTEM	27,00
GSN-333	PORTABLE VCD PLAYER WITH MP3/VCD	NO MORE AVAILABLE
GSN-173	RADIO CASSETTE RECORDER	NO MORE AVAILABLE
GSN-41	PORTABLE RADIO CASSETTE PLAYER	5,00
GSN-43	PORTABLE RADIO CASSETTE PLAYER	5,00
GSN-73	RADIO CASSETTE RECORDER	4,00
GSN-72	RADIO CASSETTE RECORDER	4,00
GSL-355	RECHARGEABLE LANTERN	4,80
GSL-358	RECHARGEABLE LANTERN	4,80
GSL-378	RECHARGEABLE LANTERN	4,80
GSL-352	RECHARGEABLE FLOREUSCENT	5,00
GSL-350	RECHARGEABLE FLOREUSCENT	4,00
GSL-368	RECHARGEABLE FLOREUSCENT	4,00
GSL-331	RECHARGEABLE FLOREUSCENT	3,80
GSL-305	HALOGEN SPOTLIGHT	3,80
GSL-299	RECHARGEABLE TORCH	2,80
GSV-1508	VACUUM CLEANER	30,00
GSV-1502	VACUUM CLEANER	34,00
GSV-1511	VACUUM CLEANER	24,00
GSV-1518	VACUUM CLEANER	34,00
GSV-1515	VACUUM CLEANER	30,00
GMO-530	MICROWAVE OVEN	38,00
GMO-525	MICROWAVE OVEN	34,00
GEO-515	OVEN TOASTER	NO MORE AVAILABLE
GEO-505	OVEN TOASTER	18,00

GEO-423	OVEN TOASTER	12,00
GEO-418	OVEN TOASTER	12,00
GEO-465	OVEN TOASTER	NO MORE AVAILABLE
GEO-455	OVEN TOASTER	NO MORE AVAILABLE
GEO-444	OVEN TOASTER	NO MORE AVAILABLE
GGC-205	OVEN TOASTER	NO MORE AVAILABLE
GGC-204	OVEN TOASTER	NO MORE AVAILABLE
GGC-203	OVEN TOASTER	NO MORE AVAILABLE
GGC-256	TRIPLE GAS COOKER	NO MORE AVAILABLE
GGC-255	SINGLE GAS COOKER	NO MORE AVAILABLE
GGC-253	HOUSEHOLD GAS STOVE	8,50
GGC-251	HOUSEHOLD GAS STOVE	3,80
GHP-144	ELECTRIC DOUBLE PLATE	6,00
GHP-142	ELECTRIC SINGLE PLATE	3,80
GHP-134	ELECTRIC DOUBLE PLATE	5,50
GHP-132	ELECTRIC SINGLE PLATE	2,50
GMG-859	MEAT GRINDER	22,00
GMG-848	MEAT GRINDER	NO MORE AVAILABLE
GMG-846	MEAT GRINDER	14,50
GMG-844	MEAT GRINDER	14,50
GRC-675	RICE COOKER	16,00
GDF-632	DEEP FRYER	13,50
GDF-628	DEEP FRYER	11,00
GDF-615	DEEP FRYER	9,80
GDF-610	DEEP FRYER	7,50
GSM-608	SANDWICH MAKER	6,00
GSM-604	SANDWICH MAKER	3,80
GSM-602	SANDWICH MAKER	3,80
GSB-829	FOOD PROCESSOR	10,00
GHM-802	MIXER WITH BOWL	13,50
GHM-813	MIXER WITH BOWL	8,50
GHM-803	MIXER WITH BOWL	7,50
GSJ-816	JUICE EXTRACTOR	15,00
GSJ-815	POWER JUICER	11,00
GST-877	TEA TRAY	NO MORE AVAILABLE
GST-875	TEA TRAY	11,00
GST-872	TEA TRAY	10,00
GST-894	TEA TRAY	8,50
GST-893	TEA TRAY	8,00
GSK-727	ELECTRIC KETTLE	5,00
GSK-709	CORDLESS ELECTRICAL KETTLE	NO MORE AVAILABLE
GSK-703	CORDLESS ELECTRICAL KETTLE	NO MORE AVAILABLE
GSK-719	ELECTRIC KETTLE	3,80
GSK-718	ELECTRIC KETTLE	3,80
GSB-868	BLENDER	8,50
GSB-838	BLENDER	8,50
GSB-825	BLENDER	5,00
GHM-809	HAND MIXER	NO MORE AVAILABLE
GSB-839	HAND BLENDER	8,50
GSB-832	HAND BLENDER	7,50
GSB-821	HAND BLENDER	3,80
GSB-810	HAND BLENDER	2,50
GSJ-805	CITRUS JUICER	6,00
GSJ-804	CITRUS JUICER	6,00

GSI-801	CITRUS JUICER	4,50
GSC-811	CHOPPER	NO MORE AVAILABLE
GSI-192	STEAM IRON	9,80
GSI-186	STEAM IRON	7,50
GSI-157	STEAM IRON	7,50
GSI-162	STEAM IRON	7,50
GSI-1188	STEAM IRON	NO MORE AVAILABLE
GSI-1168	STEAM IRON	NO MORE AVAILABLE
GSI-1138	STEAM IRON	NO MORE AVAILABLE
GSI-138	STEAM IRON	NO MORE AVAILABLE
GHD-258	HAIR DRYER	3,80
GHD-252	HAIR DRYER	3,80
GHD-224	HAIR DRYER	NO MORE AVAILABLE
GHD-235	HAIR DRYER	3,80
GHD-262	HAIR DRYER	3,80
GHD-221	HAIR DRYER	3,80
GHD-245	HAIR DRYER	2,50
GHD-230	HAIR DRYER	2,50
GHD-216	HAIR DRYER	2,50
GHD-215	HAIR DRYER	2,50
GWD-528	WATER DISPENSER	NO MORE AVAILABLE
GWD-521	WATER DISPENSER	NO MORE AVAILABLE
GWP-20	WATER PURIFIER	NO MORE AVAILABLE
GWP-21	WATER PURIFIER	NO MORE AVAILABLE
GWP-15	WATER PURIFIER	NO MORE AVAILABLE
GWP-16	WATER PURIFIER	NO MORE AVAILABLE
GSF-170	ELECTRIC FAN	NO MORE AVAILABLE
GSF-168	ELECTRIC FAN	NO MORE AVAILABLE
GSF-164	ELECTRIC FAN	NO MORE AVAILABLE
GWF-174	WALL FAN	NO MORE AVAILABLE
GWF-172	WALL FAN	NO MORE AVAILABLE
GCF-176	CEILING FAN	NO MORE AVAILABLE
GCF-175	CEILING FAN	NO MORE AVAILABLE
GEH-118	HEATER	NO MORE AVAILABLE
GEH-125	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-243	HEATER	NO MORE AVAILABLE
GEH-244	HEATER	NO MORE AVAILABLE
GEH-232	HEATER	NO MORE AVAILABLE
GEH-214	HEATER	NO MORE AVAILABLE
GEH-202	HEATER	NO MORE AVAILABLE
GEH-228	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-227	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-225	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-226	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-222	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-213	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-211	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-223	ELECTRIC HEATER	NO MORE AVAILABLE
GEH-201	ELECTRIC HEATER	NO MORE AVAILABLE
GSC-02	WALL CLOCK	NO MORE AVAILABLE
GSC-03	WALL CLOCK	NO MORE AVAILABLE